

Physico-chemical and toxicological studies of engineered nanoparticles emitted from printing equipment

Sandra V. Pirela, M.S., Philip Demokritou, Ph.D.

Doctoral Candidate

Harvard School of Public Health



HARVARD
SCHOOL OF PUBLIC HEALTH

CENTER FOR NANOTECHNOLOGY
AND NANOTOXICOLOGY
<http://hsph.harvard.edu/nano>



Background (1 of 3)


- ❖ Nanotechnology has increased significantly over last decade: benefits of unique 'nano' properties.
- ❖ A new industrial “motto” for the 21st Century: **“The NANO the better”**
- ❖ There is a growing number of products in the market which contain nanoscale materials (e.g. sunscreens, building materials, food packaging, etc).
- ❖ There is growing evidence linking nano-enabled products (NEPs) to possible exposures and adverse health effects



Background (2 of 3)

- ❖ Our group has been investigating the possible exposure to engineered nanomaterials (ENMs) included in the toner formulations and emitted from printing equipment.
- ❖ New photocopier toner formulations have switched to "nano" in order to improve quality.
 - Shift in toner composition → incorporation of nanoparticles ¹.
 - Complex elemental mixture (organic/inorganic composition)¹.
- ❖ Our recent studies from a photocopy center linked emitted PM to toxicity potential in both *in vitro* and *in vivo* experimental models ^{2,3}.

Chemical profile and imaging of the emitted PM_{0.1} size fraction



Background- Printers (3 of 3)

- ❖ Currently, our group is involved in a new study focusing on the **physico-chemical and toxicological** implications of particles emitted from consumer grade printers.
- ❖ It is well known that laser printers emit high number of nanoparticles, VOCs and ozone.
- ❖ Not much is known about engineered nanoparticles emitted from printers.
- ❖ Complex physico-chemical and morphological characteristics of both toner formulations and PEPs are unknown.




Gaps in the literature

- ❖ Physicochemical and morphological properties of PEPs remain poorly characterized.
- ❖ Unsure of the source apportionment of these emissions.
- ❖ Toxicological studies use toner particles instead of “real world” emitted particles and physiologically irrelevant doses.
- ❖ Uncertainty in the implications of shift from micron to nano-sized particles in toner formulations.
- ❖ Insufficient data for adequate science-based risk assessment of exposure in both occupational and non-occupational settings.



How do laser printers work?



Research Objectives

- ❖ Develop a lab-based exposure system and p-c-m characterization of printer emitted particles (PEPs).
 - Generation of relevant real-world particles emitted from laser printers
 - Evaluation of effect of operational parameters on printer emission profile
 - Use of the exposure system to assess emissions of commonly used printers (11 printers, various models and manufacturers).


- ❖ Physico-chemical and morphological evaluation of toner powder and PEPs.

- ❖ *In vitro* evaluation of biological outcomes
 - Exposure: Cell suspensions (single- and co-culture systems).
 - Endpoints: genotoxicity and cytotoxicity.



Objective 1: Develop lab-based exposure system to generate controlled-exposure atmospheres from laser printers

- ❖ Glovebox chamber design allowed for uninterrupted operation.
- ❖ Evaluated 11 printers of various manufacturers/brands
 - Emission profiles
 - Operational parameters
- ❖ Real time and integrated PM sampling/monitoring systems:
 - SMPS/CPC and APS
 - Ozone monitor
 - Dust track
 - Q-trak



Size distribution and number concentration of PEPs

- ❖ 11 printers from 4 manufacturers were assessed and ranked in terms of emitted particles during a continuous print job.
- ❖ Particle number concentration ranged across manufacturers and varied from 2.99×10^3 to 1.27×10^6 particles/cm³.
- ❖ Size distribution properties:
 - Mean: 39 - 122 nm
 - Majority < 100nm (none/few particles > 200 nm)
- ❖ “Initial burst” of particles at initiation of printing visible for almost all printers.
- ❖ Certain operational parameters affect printer emission profile: warm up period, page coverage, and printing mode (continuous vs. intermittent).
- ❖ No observable association between printer model/maker and emission profile.


- ❖ Collected size-fractionated PEPs and toner powder from the 6 highest-emitting laser printers.

- ❖ Performed the following chemical and morphological analyses:
 - SF-ICP-MS: metals
 - GC-MS: organic and elemental carbon
 - TEM/SEM: morphology
 - EDS: surface chemistry


Results:

Chemical composition of toner powder and PEPs

Toner powder (Manufacturer A and B)



PEPs (Manufacturer A and B)





- ❖ Toner powder and PEPs **share** complex chemical composition (metals, OC, EC, organometallic salts).
- ❖ Organic carbon: toner powder 42-89%, PEPs 40-99%.
- ❖ Metals: toner powder 1-34%, PEPs 1-3%. These include: CeO₂, ZnO and CuO.
- ❖ Elements from toner were identified in PEPs at different concentrations, indicative of PM emitted from toner.
- ❖ Some metals found in PEPs and paper, but not in toner powder → paper as a PM emission source.

(Unpublished data, manuscripts in preparation)

Results:



Morphological characterization of toner powders

Manufacturer 1, Model A



- ❖ Nanoparticles are visible on surface of toner powder of two models of same manufacturer.
- ❖ Irregular particles with diameter of 10 μm.
- ❖ Traces of carbon, oxygen, aluminum, silicon, cerium and lanthanum, among others was confirmed in EDS analysis.

Manufacturer 1, Model B:





Confirmation: toner formulations switched from micron to nano.

(Unpublished data, manuscripts in preparation)





Morphological characterization of PEPs

Manufacturer 1, Model A



- ❖ Size of aggregates ranged from 20 – 200 nm.
 - Consistent with real-time monitoring instrumentation.
- ❖ Irregularly-shaped particles.

Manufacturer 1, Model B



Confirmation: ENMs are making their way to room air during printing.

(Unpublished data, manuscripts in preparation)

Objective 3: Characterize biological outcomes *in vitro* due to exposures to PEPs

Cells

- Single and co-culture systems
- SAEC, HMVEC, THP-1 and TK-6

Exposure

- Duration: 24 hours
- Dose: 5, 20, 40 and 100 $\mu\text{g/ml}$

Particles


- PEPs ($\text{PM}_{0.1}$, $\text{PM}_{0.1-2.5}$ and $\text{PM}_{<2.5}$)
- Comparative particles (SiO_2 , MS-welding fumes)

Endpoints


- DNA damage
- Cell viability
- Morphology
- Membrane injury
 - Migration
 - Inflammation
- ROS generation

Results:

preliminary *in vitro* toxicological characterization of PEPs



- ❖ LDH assay performed 24 hrs post-exposure to PEPs
- ❖ Dose response
- ❖ Different toxicity of PM_{0.1-2.5} and PM_{0.1}
- ❖ PM_{0.1} more toxic than welding fumes.



Cellular membrane integrity has been affected by the exposure to PEPs → concerns for lung toxicity

Conclusions

- ❖ A substantial number of engineered nanoparticles are emitted during printing.
- ❖ Toner formulations contain nanoscale materials, which become airborne during the printing process.
- ❖ Complexity of chemical composition of PEPs raises concern for toxicity.
- ❖ Preliminary *in vitro* data → possible adverse health implications.

Future directions: *in vivo* toxicological characterization using a mouse model to evaluate biological responses in the lung following exposure to PEPs.



Acknowledgements



❖ Demokritou Laboratory

- Philip Demokritou (PI)
- George Pyrgiotakis
- George Sotiriou
- Bingtao Zhao

❖ Consumer Product Safety Commission

- Treye Thomas

❖ NIOSH

- Vincent Castranova
- Yong Qian
- Jennifer Sisler

QUESTIONS?



HARVARD
SCHOOL OF PUBLIC HEALTH

CENTER FOR NANOTECHNOLOGY
AND NANOTOXICOLOGY

<http://hsph.harvard.edu/nano>



CENTER FOR NANOTECHNOLOGY
AND NANOTOXICOLOGY @ HSPH
<http://hsph.harvard.edu/nano>

Possible Sources of printer emissions

Paper

CaCO_3

Organic compounds
deriving from the
degradation of
cellulose.

Toner

Plastic (Styrene acrylate copolymer,
polyester resin): 65-85% or 55-65%.

Iron oxide: 6-12% or 30-40%.

Wax, ground sand: 1-5%.

Amorphous silica: 1-3 %.

Carbon black: 1-10%.

Other metals.

Casing/Structure

Plastic.

Flame retardants
(brominated).

Fillers (silica).

Micron → nano ?

References: Paper (Gaspar et al., 2010, Ramalho et al., 2009), Toner (Dell MSDS), Casing (Barthel et al., 2011).

